

## Warmington Gas Fires Smartphone App Instructions

The app can be used both on iOS and Android devices they can be downloaded here:

Apple Store: <https://apps.apple.com/jm/app/intelligy-thermostat-mkii/id1327577138>

Google Play Store: <https://play.google.com/store/apps/details?id=com.millec.intelligythermostat>


Or search for “Intelligy Thermostat MKII” in your smart phone app store.

For instructions on how to push the appliance to your Wi-Fi read “Step by Step—pushing the Fireplace to a local network” on page 3 and 4.


The app has both manual control and automatic controls.

In manual control you can adjust the flame height by touching the < and > symbols next to the flame icon.

In automatic control you can adjust the desired room temperature by touching the < and > symbols next to the temperature.



Manual



Automatic

Due to continued product improvement, Warmington Ind LTD reserves the right to change product specifications without prior notification.

## WiFi Set-up

From Factory settings the Fireplace will broadcast an Access Point for the Mobile App to join with, the Access point names have the following format, Intelligy\_XXXXXX.

Where 'XXXXXX' is the last six digits of the WiFi modules MAC addresses, the Access point is secured with the default password 'intelligy'.

Joining the access point in this mode will allow you to:

- Control the Fireplace via its own WiFi Access point, and is good for Demo and testing functionality
- Push the Fireplace to a local or home network, this allows you to control the Fireplace whilst also being able to use your local network resource such as Internet, email and Facebook.
- This mode is required to utilise the Server control features of the Fireplace.

## Pushing the Fireplace to a different home or local network after initial install


Pushing the Fireplace to a different home or local network after it has previously been set up is done at Fireplace power on, when the fireplace is powered off at the Main switch, upon being powered on, the Fireplace will show its Access Point (Intelligy\_XXXXXX) for 30 Seconds.

If you join the Access Point with your mobile device, you will be able to change the network the Fireplace is currently connected with via the mobile App.


If you do not join the Access Point the Fireplace will join the network that it has settings saved for or if there are no settings, it will stay in Access Point mode.

**Note** if you join the Access Point by accident on power on, you can simply power off the Fireplace and power on again, after the 30 seconds the Fireplace will join the network it has saved settings for.


Step by Step—pushing the Fireplace to a local network




Open up the WiFi settings on your smart device.




Select the Intelligy\_XXXXXX access point.




Enter the default password 'intelligy'.




Ensure it has been successfully connected. 'No internet' is correct.




Open up the app on your smart device.



When prompted select "Connect to network"



Then select your home WiFi network



The app will begin to search for devices on the chosen network, and ready to be used as explained on page 1.